

MOTOMAN-MS210, MH225 INSTRUCTIONS

**SUPPLEMENTARY FOR TYPE:
YR-MS210/MH225-X00 (MINIMIZING MACHINE DIFFERENCE SPECIFICATION)**

Upon receipt of the product and prior to initial operation, read these instructions thoroughly, and retain for future reference.

MOTOMAN INSTRUCTIONS

- MOTOMAN-MS210 INSTRUCTIONS
- MOTOMAN-MH225 INSTRUCTIONS
- DX200 INSTRUCTIONS
- DX200 OPERATOR'S MANUAL (for each purpose)
- DX200 MAINTENANCE MANUAL

The DX200 operator's manual above corresponds to specific usage. Be sure to use the appropriate manual.

Part Number: 171269-1CD
Revision: 0

Copyright © 2014, Yaskawa America, Inc. All Rights Reserved.

1 Introduction

This supplementary instruction manual describes how YR-MS210/MH225-X00 (hereinafter referred to as MS210/MH225-X00) is different from the YR-MS210/MH225-A00 (hereinafter referred to as MS210/MH225-A00).

In case of using MS210/MH225-X00, read this supplementary instruction manual thoroughly with: "MOTOMAN-MS210 INSTRUCTIONS" (165835-1CD) or "MOTOMAN-MH225 INSTRUCTIONS" (167107-1CD).

1.1 Point of Difference

MS210/MH225-X00 differ from the MS210/MH225-A00 in the following point:

1. Recommended Spare Parts

- S-, L-, U-, R-, B- and T-Axes Speed Reducer
- Wrist Unit

The differences are described based on "MOTOMAN-MS210 INSTRUCTIONS" (165835-1CD) or "MOTOMAN-MH225 INSTRUCTIONS" (167107-1CD). Read this manual thoroughly replacing the subject matters for changes with this supplementary instruction manual.

2 Recommended Spare Parts (Page 10-1)

Replace the corresponding items in *Table 10-1 "Spare Parts for the YR-MS210/MH225-A00"* with the following items.

Table 2-1: Spare Parts for the YR-MS210/MH225-X00

Rank	Parts No.	Name	Type	Manufacturer	Qty	Qty per Unit	Remarks
B	6	Replacement Kit for S-Axis Speed Reducer	Y005C-MSMH225X00S	Yaskawa	1	1	
B	7	Replacement Kit for L-Axis Speed Reducer	Y005C-MSMH225X00L	Yaskawa	1	1	
B	8	Replacement Kit for U-Axis Speed Reducer	Y005C-MSMH225X00U	Yaskawa	1	1	
B	9	Replacement Kit for R-Axis Speed Reducer	Y005C-MSMH225X00R	Yaskawa	1	1	
B	10	Replacement Kit for B-Axis Speed Reducer	Y005C-MSMH225X00B	Yaskawa	1	1	
B	11	Replacement Kit for T-Axis Speed Reducer	Y005C-MSMH225X00T	Yaskawa	1	1	
B	13	Wrist Unit	HW1171444-X	Yaskawa	1	1	

Revision History

Date	CEN / ECN	Revision No.	Reason For Revision	Initials
10/28/2014	58975	0	Original Release	JFC

MOTOMAN-MS210, MH225 INSTRUCTIONS

SUPPLEMENTARY FOR TYPE: YR-MS210/MH225-X00 (MINIMIZING MACHINE DIFFERENCE SPECIFICATION)

HEAD OFFICE

2-1 Kurosakishiroishi, Yahatanishi-ku, Kitakyushu 806-0004, Japan
Phone +81-93-645-7703 Fax +81-93-645-7802

YASKAWA America Inc. (Motoman Robotics Division)
100 Automation Way, Miamisburg, OH 45342, U.S.A.
Phone +1-937-847-6200 Fax +1-937-847-6277

YASKAWA Europe GmbH (Robotics Division)
Yaskawastrasse 1, 85391 Allershausen, Germany
Phone +49-8166-90-100 Fax +49-8166-90-103

YASKAWA Nordic AB
Bredbandet 1 vån. 3 varvsholmen 392 30 Kalmar, Sweden
Phone +46-480-417-800 Fax +46-480-417-999

YASKAWA Electric (China) Co., Ltd.
22/F One Corporate Avenue No.222, Hubin Road, Huangpu District, Shanghai 200021, China
Phone +86-21-5385-2200 Fax +86-21-5385-3299

YASKAWA SHOUGANG ROBOT Co. Ltd.
No7 Yongchang North Road, Beijing E&T Development Area, China 100176
Phone +86-10-6788-2858 Fax +86-10-6788-2878

YASKAWA India Private Ltd. (Robotics Division)
#426, Udyog Vihar, Phase- IV, Gurgaon, Haryana, India
Phone +91-124-475-8500 Fax +91-124-475-8542

YASKAWA Electric Korea Co., Ltd
9F, Kyobo Securities Bldg., 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul 150-737, Korea
Phone +82-2-784-7844 Fax +82-2-784-8495

YASKAWA Electric Taiwan Corporation
12F, No.207, Sec. 3, Beishin Rd., Shindian District, New Taipei City 23143, Taiwan
Phone +886-2-8913-1333 Fax +886-2-8913-1513

YASKAWA Electric (Singapore) PTE Ltd.
151 Lorong Chuan, #04-02A, New Tech Park, Singapore 556741
Phone +65-6282-3003 Fax +65-6289-3003

YASKAWA Electric (Thailand) Co., Ltd.
252/125-126 27th Floor, Tower B Muang Thai-Phatra Complex Building,
Rachadaphisek Road, Huaykwang, Bangkok 10320, Thailand
Phone +66-2693-2200 Fax +66-2693-4200

PT. YASKAWA Electric Indonesia
Menara Anugrah Lantai 1, Kantor Taman E.3.3, Jl Mega Kuningan Lot 8.6-8.7, Kawasan
Mega Kuningan, Jakarta, Indonesia
Phone +62-21-57941845 Fax +62-21-57941843

Specifications are subject to change without notice
for ongoing product modifications and improvements.