

MOTOMAN NEWS RELEASE

FOR IMMEDIATE RELEASE
SEPTEMBER 2006

CONTACT: Sally Fairchild
937.847.3202

MODULAR MOTOMAN MH1500-450 TR PART POSITIONER IDEAL FOR ARC WELDING



Dayton, Ohio — Motoman's economical new MH1500-450 TR positioner is comprised of two standard headstock modules combined to provide highly flexible, AC servo-controlled tilt/rotate part positioning using two rotational axes of motion. Positioner motion can be coordinated with the robot motion to keep weld joints oriented in an ideal posture for welding and to allow circumferential welds to be performed in a single pass.

Designed to accommodate small- to medium-sized parts, the MH1500-450 TR position features a 450 kg (992.25-lb) payload rated at a 75 mm (2.95") overhang. Tilt axis speed is 10.6 rpm and rotate axis speed is 9.8 rpm. The positioner also features integrated weld grounds and safety switches.

Motoman's extensive line of single and multi-axis part positioners includes headstocks/positioner assemblies with payloads from 75-3,000 kg payloads.

For more information on Motoman products and services, visit the corporate website at www.motoman.com, call 937.847.6200, or write to Motoman Inc., 805 Liberty Lane, West Carrollton, Ohio, USA 45449.

###