

CONTACT:
Sally Fairchild
Sr. Mgr., Marketing
937.847.3202

**NEW! MOTOMAN ROBOTICS ADDS MPP3 DELTA STYLE ROBOT TO PRODUCT LINE
HIGH-SPEED, POWERFUL MPP3 ROBOT IDEAL FOR HIGH-SPEED
PACKAGING, CARTONING AND KITTING APPLICATIONS**



DAYTON, OH (SEPTEMBER 2011) — Introduced at Pack Expo (Sept 26, 2011 | Las Vegas), the delta-style Motoman® MPP3 robot provides superior performance for high-speed packaging, cartoning and kitting applications. Its high-speed operation – up to 150 cycles per minute – yields extraordinary production results.

The MPP3 robot features a three-arm configuration with a direct-driven rotary axis to simplify design and increase reliability. With a minimum installation area and the smallest footprint in its class, the MPP3 robot is ideal for high-density installations, while providing a large working envelope.

“The release of the MPP3 robot rounds out our comprehensive product offering in the packaging market,” stated Dean Elkins, Sr. General Sales Manager, Motoman Robotics. “Our customers benefit from highly reliable manipulators and a common programming language in picking, packaging and palletizing applications,” he added.

The MPP3 robot is IP65-rated and features a 3 kg payload capability; a deep work envelope up to 500 mm; and a repeatability of ± 0.1 mm (± 0.004 ”). It is available with optional vision and conveyor tracking.

The MPP3 uses the new FS100 controller, the smallest controller in its class at just 19” wide. It features a high-speed open architecture design that allows software and system flexibility. The FS100 supports C, C#, INFORM III and other high-level programming environments.

About Motoman Robotics Division

Founded in 1989, the Motoman Robotics Division of Yaskawa America, Inc. is a leading robotics company in the Americas. With over 230,000 Motoman® robots installed globally, Yaskawa provides automation products and solutions for virtually every industry and robotic application; including arc welding, assembly, coating, dispensing, material handling, material cutting, material removal, packaging, palletizing and spot welding. For more information please visit our website at www.motoman.com or call 937.847.6200.

###